4860 HD (250-3540) Using the SWITCHER.EXE Utility Faxback Doc. # 1069

Note: Refer to Faxback Doc. # 1088 for Installation Instructions from the Utilities Disk.

SWITCHER duplicates many VGACONF options. However, SWITCHER loads into memory so you can always access the options. When you install SWITCHER you can change many video options by pressing special key sequences.

NOTES:

- \* When you run SWITCHER, you reduce the total amount of memory available to DOS program.
- \* SWITCHER does not function while you are running Windows and some other applications that directly control the keyboard and display.
- \* Refer to "Using the VGACONF Utility" for a complete description of all options except "Screen Power" and "Suspend Mode".

Type the following command from the C:\ prompt to run SWITCHER:

CD \CDUTIL <ENTER> SWITCHER <ENTER>

KEYSTROKE	FEATURE
CTRL+SHIFT+A	Contrast enhancement ON/OFF
CTRL+SHIFT+B	Switch between bold text allowed and disallowed
CTRL+SHIFT+C	Switch between vertical positioning options (Top, Center, Bottom) for unexpanded screens
CTRL+SHIFT+D	Switch between an external monitor, both the built- in screen & an external monitor, & only the built- in screen
CTRL+SHIFT+E	Expand mode ON/OFF
CTRL+SHIFT+G	Cycles through each of the gray scale settings
CTRL+SHIFT+L	Inhibit font loading ON/OFF for an external monitor
CTRL+SHIFT+O	Full height cursor ON/OFF
CTRL+SHIFT+R	Reverse video ON/OFF
CTRL+SHIFT+S	Screen Power ON/OFF (Built-in screen only)
CTRL+SHIFT+U	Suspend Mode ON/OFF (Built-in screen only)

Now you can use these key sequences to change the video options:

All SWITCHER commands operate in toggle mode. That is, each time you press a key sequence, you change the option's setting.

Screen power ON/OFF (CTRL+SHIFT+S) turns the built-in display on and off. This option does not affect an external monitor.

Suspend mode ON/OFF (CTRL+SHIFT+U) temporarily suspends operation if you are using the built-in screen. This option has no effect when you use an external monitor.