

Accessory	Description	Computer Model
PA2000U	2MB MEMORY KIT	T1800
PA2000U	2MB MEMORY KIT	T1850/C
PA2000U	2MB MEMORY KIT	T2000SXE
PA2000U	2MB MEMORY KIT	T2200SX
PA2001U	4MB MEMORY KIT	T1800
PA2001U	4MB MEMORY KIT	T1850/C
PA2001U	4MB MEMORY KIT	T2000SXE
PA2001U	4MB MEMORY KIT	T2200SX
PA2002U	8MB MEMORY KIT	T1800
PA2002U	8MB MEMORY KIT	T1850/C
PA2002U	8MB MEMORY KIT	T2000SXE
PA2002U	8MB MEMORY KIT	T2200SX
PA2003U	2MB MEMORY KIT	T4400 series
PA2003U	2MB MEMORY KIT	T6400 series
PA2004U	4MB MEMORY KIT	T4400 series
PA2004U	4MB MEMORY KIT	T6400 series
PA2004U	4MB MEMORY KIT	T6600C
PA2005U	8MB MEMORY KIT	T4400 series
PA2005U	8MB MEMORY KIT	T6400 series
PA2006U	2MB MEMORY KIT	T3300SL
PA2007U	4MB MEMORY KIT	T3300SL
PA2008U	6MB MEMORY KIT	T3300SL
PA2009U	16MB MEMORY KIT	T3300SL
PA2010U	16MB MEMORY KIT	T4400 series
PA2010U	16MB MEMORY KIT	T6400 series
PA2010U	16MB MEMORY KIT	T6600C
PA2011U	2MB MEMORY KIT	T4500
PA2011U	2MB MEMORY KIT	T4500C
PA2011U	2MB MEMORY KIT	T4600
PA2011U	2MB MEMORY KIT	T4600C
PA2012U	4MB MEMORY KIT	T1900/C
PA2012U	4MB MEMORY KIT	T1900S
PA2012U	4MB MEMORY KIT	T1910
PA2012U	4MB MEMORY KIT	T1910CS
PA2012U	4MB MEMORY KIT	T1950
PA2012U	4MB MEMORY KIT	T1950CS/CT
PA2012U	4MB MEMORY KIT	T1960CS/CT
PA2012U	4MB MEMORY KIT	T200/CS
PA2012U	4MB MEMORY KIT	T4500
PA2012U	4MB MEMORY KIT	T4500C
PA2012U	4MB MEMORY KIT	T4600
PA2012U	4MB MEMORY KIT	T4600C
PA2012U	4MB MEMORY KIT	T4700CS
PA2012U	4MB MEMORY KIT	T4700CT
PA2012U	4MB MEMORY KIT	T4800CT
PA2012U	4MB MEMORY KIT	T4850CT
PA2012U	4MB MEMORY KIT	T4900CT
PA2013U	8MB MEMORY KIT	T1900/C
PA2013U	8MB MEMORY KIT	T1900S
PA2013U	8MB MEMORY KIT	T1910/CS
PA2013U	8MB MEMORY KIT	T1950
PA2013U	8MB MEMORY KIT	T1950CS/CT
PA2013U	8MB MEMORY KIT	T1960CS/CT
PA2013U	8MB MEMORY KIT	T200/CS
PA2013U	8MB MEMORY KIT	T4500/C
PA2013U	8MB MEMORY KIT	T4600/C
PA2013U	8MB MEMORY KIT	T4700CS/CT

PA2013U	8MB MEMORY KIT	T4800CT
PA2013U	8MB MEMORY KIT	T4850CT
PA2013U	8MB MEMORY KIT	T4900CT
PA2014U	16MB MEMORY KIT	T1900/C
PA2014U	16MB MEMORY KIT	T1900S
PA2014U	16MB MEMORY KIT	T1910/CS
PA2014U	16MB MEMORY KIT	T1950
PA2014U	16MB MEMORY KIT	T1950CS/CT
PA2014U	16MB MEMORY KIT	T1960CS/CT
PA2014U	16MB MEMORY KIT	T200/CS
PA2014U	16MB MEMORY KIT	T4500
PA2014U	16MB MEMORY KIT	T4500C
PA2014U	16MB MEMORY KIT	T4600
PA2014U	16MB MEMORY KIT	T4600C
PA2014U	16MB MEMORY KIT	T4700CS/CT
PA2014U	16MB MEMORY KIT	T4800CT
PA2014U	16MB MEMORY KIT	T4850CT
PA2014U	16MB MEMORY KIT	T4900CT
PA2016U	4MB MEMORY KIT	T100X
PA2017U	6MB MEMORY KIT	T100X
PA2019U	4MB MEMORY KIT	T2400CS/CT
PA2019U	4MB MEMORY KIT	T2450CT
PA2019U	4MB MEMORY KIT	T3400
PA2019U	4MB MEMORY KIT	T3400CT
PA2019U	4MB MEMORY KIT	T3600CT
PA2020U	8MB MEMORY KIT	T2400CS
PA2020U	8MB MEMORY KIT	T2400CT
PA2020U	8MB MEMORY KIT	T2450CT
PA2020U	8MB MEMORY KIT	T3400
PA2020U	8MB MEMORY KIT	T3400CT
PA2020U	8MB MEMORY KIT	T3600CT
PA2021U	16MB MEMORY KIT	T2450CT
PA2021U	16MB MEMORY KIT	T3400
PA2021U	16MB MEMORY KIT	T3400CT
PA2023U	16MB MEMORY KIT	T2400CS
PA2023U	16MB MEMORY KIT	T2400CT
PA2023U	16MB MEMORY KIT	T3600CT
PA2026U	4MB MEMORY KIT	T2100
PA2026U	4MB MEMORY KIT	T2100CS
PA2026U	4MB MEMORY KIT	T2100CT
PA2026U	4MB MEMORY KIT	T2110
PA2026U	4MB MEMORY KIT	T2110CS
PA2026U	4MB MEMORY KIT	T2130CS
PA2026U	4MB MEMORY KIT	T2130CT
PA2026U	4MB MEMORY KIT	T2150CDS/CDT
PA2027U	8MB MEMORY KIT	T2100/CS/CT
PA2027U	8MB MEMORY KIT	T2110
PA2027U	8MB MEMORY KIT	T2110CS
PA2027U	8MB MEMORY KIT	T2130CS
PA2027U	8MB MEMORY KIT	T2130CT
PA2027U	8MB MEMORY KIT	T2150CDS
PA2027U	8MB MEMORY KIT	T2150CDT
PA2028U	16MB MEMORY KIT	T2100
PA2028U	16MB MEMORY KIT	T2100CS
PA2028U	16MB MEMORY KIT	T2100CT
PA2028U	16MB MEMORY KIT	T2110
PA2028U	16MB MEMORY KIT	T2110CS
PA2028U	16MB MEMORY KIT	T2130CS
PA2028U	16MB MEMORY KIT	T2130CT
PA2028U	16MB MEMORY KIT	T2150CDS
PA2028U	16MB MEMORY KIT	T2150CDT

PA2029U	24MB MEMORY KIT	T2100
PA2029U	24MB MEMORY KIT	T2100CS
PA2029U	24MB MEMORY KIT	T2100CT
PA2029U	24MB MEMORY KIT	T2110
PA2029U	24MB MEMORY KIT	T2110CS
PA2029U	24MB MEMORY KIT	T2130CS
PA2029U	24MB MEMORY KIT	T2130CT
PA2029U	24MB MEMORY KIT	T2150CDS
PA2029U	24MB MEMORY KIT	T2150CDT
PA2031U	8MB MEMORY KIT	Portege 610CT
PA2031U	8MB MEMORY KIT	Satellite 100CS
PA2031U	8MB MEMORY KIT	Satellite Pro 400CDT
PA2031U	8MB MEMORY KIT	Satellite Pro 400CS
PA2031U	8MB MEMORY KIT	Satellite Pro 410CDT
PA2031U	8MB MEMORY KIT	Satellite Pro 410CS
PA2032U	16MB MEMORY KIT	Portege 610CT
PA2032U	16MB MEMORY KIT	Satellite 400CS
PA2032U	16MB MEMORY KIT	Satellite Pro 400CDT
PA2032U	16MB MEMORY KIT	Satellite Pro 400CS
PA2032U	16MB MEMORY KIT	Satellite Pro 410CDT
PA2032U	16MB MEMORY KIT	Satellite Pro 410CS
PA2034U	32MB MEMORY KIT	Portege 610CT
PA2034U	32MB MEMORY KIT	Satellite 100CS
PA2034U	32MB MEMORY KIT	Satellite Pro 400CDT
PA2034U	32MB MEMORY KIT	Satellite Pro 400CS
PA2034U	32MB MEMORY KIT	Satellite Pro 410CDT
PA2034U	32MB MEMORY KIT	Satellite Pro 410CS
PA2035U	8MB MEMORY KIT	Tecra 700CS/CT
PA2035U	8MB MEMORY KIT	Tecra 710CDT
PA2035U	8MB MEMORY KIT	Tecra 720CDT
PA2036U	16MB MEMORY KIT	Tecra 700CS/CT
PA2036U	16MB MEMORY KIT	Tecra 710CDT
PA2036U	16MB MEMORY KIT	Tecra 720CDT
PA2037U	32MB MEMORY KIT	Tecra 700CS/CT
PA2037U	32MB MEMORY KIT	Tecra 710CDT
PA2037U	32MB MEMORY KIT	Tecra 720CDT
PA2400U (E/Y)	AC ADAPTER	T2000
PA2400U (E/Y)	AC ADAPTER	T2200SX
PA2400U (E/Y)	AC ADAPTER	T3300SL
PA2403E	MAIN BATTERY	T2000
PA2404U	MAIN BATTERY	T2200SX
PA2404U	MAIN BATTERY	T3300SL
PA2407U	MAIN BATTERY	T4400 series
PA2408U (Y)	AC ADAPTER	T4400 series
PA2409U (E/Y)	AC ADAPTER	T1800
PA2409U (E/Y)	AC ADAPTER	T1850
PA2410U (R)	MAIN BATTERY	T1800
PA2410U (R)	MAIN BATTERY	T1850/C
PA2411U (E/Y)	AC ADAPTER	T1850C
PA2411U (E/Y)	AC ADAPTER	T4500/C
PA2411U (E/Y)	AC ADAPTER	T4600
PA2411U (E/Y)	AC ADAPTER	T4600C
PA2412U (R)	MAIN BATTERY	T4500
PA2412U (R)	MAIN BATTERY	T4600
PA2413U (R)	MAIN BATTERY	T4500C
PA2413U (R)	MAIN BATTERY	T4600C
PA2414U	MAIN BATTERY	T100X
PA2415U	BATTERY CHARGER	T100X
PA2416U (E/Y)	AC ADAPTER	T100X
PA2417U (E/Y)	AC ADAPTER	T1900
PA2417U (E/Y)	AC ADAPTER	T1900S

PA2417U (E/Y)	AC ADAPTER	T1910
PA2417U (E/Y)	AC ADAPTER	T1950
PA2420U (X/XR/XRA)	MAIN BATTERY	T1900
PA2420U (X/XR/XRA)	MAIN BATTERY	T1900C
PA2420U (X/XR/XRA)	MAIN BATTERY	T1910
PA2420U (X/XR/XRA)	MAIN BATTERY	T1910CS
PA2420U (X/XR/XRA)	MAIN BATTERY	T1950
PA2420U (X/XR/XRA)	MAIN BATTERY	T1950CS/CT
PA2420U (X/XR/XRA)	MAIN BATTERY	T4700CS/CT
PA2422U (E/Y)	BATTERY CHARGER	T1900S
PA2422U (E/Y)	BATTERY CHARGER	T1910
PA2422U (E/Y)	BATTERY CHARGER	T1910CS
PA2422U (E/Y)	BATTERY CHARGER	T1950
PA2422U (E/Y)	BATTERY CHARGER	T1950CS/CT
PA2422U (E/Y)	BATTERY CHARGER	T1960CS/CT
PA2422U (E/Y)	BATTERY CHARGER	T2400CS
PA2422U (E/Y)	BATTERY CHARGER	T2400CT
PA2422U (E/Y)	BATTERY CHARGER	T2450CT
PA2422U (E/Y)	BATTERY CHARGER	T4900CT
PA2423U	AUTOMOBILE POWER ADAPTER	T1900
PA2423U	AUTOMOBILE POWER ADAPTER	T1900C
PA2424U (R)	BATTERY PACK	T100X
PA2425U (E/Y)	BATTERY CHARGER	T100X
PA2426U (E/Y)	AC ADAPTER	T200/CS
PA2426U (E/Y)	AC ADAPTER	T3400
PA2426U (E/Y)	AC ADAPTER	T3400CT
PA2426U (E/Y)	AC ADAPTER	T3600CT
PA2427U (R)	BATTERY PACK	T200/CS
PA2428U	BATTERY CHARGER	T200/CS
PA2429U (R)	MAIN BATTERY	T2450CT
PA2429U (R)	MAIN BATTERY	T4850CT
PA2429U (R)	MAIN BATTERY	T4900CT
PA2429U (X/XR/XRA)	MAIN BATTERY	T1900S
PA2429U (X/XR/XRA)	MAIN BATTERY	T1910
PA2429U (X/XR/XRA)	MAIN BATTERY	T1910CS
PA2429U (X/XR/XRA)	MAIN BATTERY	T1960CS
PA2429U (X/XR/XRA)	MAIN BATTERY	T1960CT
PA2429U (X/XR/XRA)	MAIN BATTERY	T2400CS
PA2429U (X/XR/XRA)	MAIN BATTERY	T2400CT
PA2429U (X/XR/XRA)	MAIN BATTERY	T4800CT
PA2430U (E/Y)	AC ADAPTER	T2400CS
PA2430U (E/Y)	AC ADAPTER	T2400CT
PA2430U (E/Y)	AC ADAPTER	T2450CT
PA2431U (E/Y)	AC ADAPTER	T4850CT
PA2431U (E/Y)	AC ADAPTER	T4900CT
PA2436U (Y)	BATTERY CHARGER	Satellite 100CS
PA2436U (Y)	BATTERY CHARGER	T2100
PA2436U (Y)	BATTERY CHARGER	T2100CS
PA2436U (Y)	BATTERY CHARGER	T2100CT
PA2436U (Y)	BATTERY CHARGER	T2110
PA2436U (Y)	BATTERY CHARGER	T2110CS
PA2436U (Y)	BATTERY CHARGER	T2130CS
PA2436U (Y)	BATTERY CHARGER	T2130CT
PA2436U (Y)	BATTERY CHARGER	T2150CDS
PA2436U (Y)	BATTERY CHARGER	T2150CDT
PA2437U (R)	MAIN BATTERY	Satellite 100CS
PA2437U (R)	MAIN BATTERY	T2100
PA2437U (R)	MAIN BATTERY	T2100CS
PA2437U (R)	MAIN BATTERY	T2100CT
PA2437U (R)	MAIN BATTERY	T2110
PA2437U (R)	MAIN BATTERY	T2110CS

PA2437U (R)	MAIN BATTERY	T2130CS
PA2437U (R)	MAIN BATTERY	T2130CT
PA2437U (R)	MAIN BATTERY	T2150CDS
PA2437U (R)	MAIN BATTERY	T2150CDT
PA2438U (E)	AC ADAPTER	Portege 610CT
PA2478U (E/Y)	AC ADAPTER	T1900C
PA2478U (E/Y)	AC ADAPTER	T1910CS
PA2478U (E/Y)	AC ADAPTER	T1950CS/CT
PA2478U (E/Y)	AC ADAPTER	T1960CS/CT
PA2478U (E/Y)	AC ADAPTER	T4700CS/CT
PA2478U (E/Y)	AC ADAPTER	T4800CT
PA2481U	MAIN BATTERY	T3400
PA2481U	MAIN BATTERY	T3400CT
PA2482U	BATTERY CHARGER	T3400
PA2482U	BATTERY CHARGER	T3400CT
PA2482U	BATTERY CHARGER	T3600CT
PA2483U (R)	MAIN BATTERY	T3600CT
PA2484U (E)	AC ADAPTER	Tecra 700CS/CT
PA2484U (E)	AC ADAPTER	Tecra 710CDT
PA2484U (E)	AC ADAPTER	Tecra 720CDT
PA2485U (R)	MAIN BATTERY	Tecra 700CS/CT
PA2485U (R)	MAIN BATTERY	Tecra 710CDT
PA2485U (R)	MAIN BATTERY	Tecra 720CDT
PA2486U (E)	BATTERY CHARGER	Tecra 700CS/CT
PA2486U (E)	BATTERY CHARGER	Tecra 710CDT
PA2486U (E)	BATTERY CHARGER	Tecra 720CDT
PA2487U (R)	MAIN BATTERY	Satellite Pro 400CDT
PA2487U (R)	MAIN BATTERY	Satellite Pro 400CS
PA2487U (R)	MAIN BATTERY	Satellite Pro 410CDT
PA2487U (R)	MAIN BATTERY	Satellite Pro 410CS
PA2488U (E/Y)	BATTERY CHARGER	Satellite Pro 400CDT
PA2488U (E/Y)	BATTERY CHARGER	Satellite Pro 400CS
PA2488U (E/Y)	BATTERY CHARGER	Satellite Pro 410CDT
PA2488U (E/Y)	BATTERY CHARGER	Satellite Pro 410CS
PA2489U (R)	MAIN BATTERY	Portege 610CT
PA2602U	FDD 3.5 INCH	T100X
PA2603U	EXPANSION HDD (1.0GB)	T6600C
PA2606U	FDD 3.5 INCH	T200/CS
PA2650U	STYLUS PEN	T100X
PA2651U	STYLUS PEN	T200/CS
PA2652U	FDD 3.5 INCH	Portege 610CT
PA2652U	FDD 3.5 INCH	T2150CDS
PA2652U	FDD 3.5 INCH	T2150CDT
PA2653U	CD-ROM	Satellite Pro 400CDT
PA2653U	CD-ROM	Satellite Pro 400CS
PA2653U	CD-ROM	Satellite Pro 410CDT
PA2653U	CD-ROM	Satellite Pro 410CS
PA2653U	CD-ROM	Tecra 700CS
PA2653U	CD-ROM	Tecra 700CT
PA2700U (E/EY/U X)	DESK STATION	T2200SX
PA2700U (E/EY/U X)	DESK STATION	T3300SL
PA2700U (E/EY/U X)	DESK STATION	T4400 series
PA2701U (E/EY)	DESK STATION	T4500
PA2701U (E/EY)	DESK STATION	T4500C
PA2701U (E/EY)	DESK STATION	T4600
PA2701U (E/EY)	DESK STATION	T4600C
PA2701U (E/EY)	DESK STATION	T4700CS/CT
PA2701U (E/EY)	DESK STATION	T4800CT
PA2701U (E/EY)	DESK STATION	T4850CT
PA2701U (E/EY)	DESK STATION	T4900CT
PA2703U	PORT REPLICATOR	Portege 610CT

PA2703U	PORT REPLICATOR	T3400
PA2703U	PORT REPLICATOR	T3400CT
PA2703U	PORT REPLICATOR	T3600CT
PA2704U	PORT REPLICATOR	T2400CS
PA2704U	PORT REPLICATOR	T2400CT
PA2704U	PORT REPLICATOR	T2450CT
PA2708U (Y)	PORT REPLICATOR	T2100
PA2708U (Y)	PORT REPLICATOR	T2100CS
PA2708U (Y)	PORT REPLICATOR	T2100CT
PA2708U (Y)	PORT REPLICATOR	T2110
PA2708U (Y)	PORT REPLICATOR	T2110CS
PA2708U (Y)	PORT REPLICATOR	T2130CS
PA2708U (Y)	PORT REPLICATOR	T2130CT
PA2708U (Y)	PORT REPLICATOR	T2150CDS
PA2708U (Y)	PORT REPLICATOR	T2150CDT
PA2710U (E/EY)	DESK STATION	Tecra 710CDT
PA2710U (E/EY)	DESK STATION	Tecra 720CDT
PA2711U	PORT REPLICATOR	Satellite Pro 400CDT
PA2711U	PORT REPLICATOR	Satellite Pro 400CS
PA2711UX (YX)	PORT REPLICATOR	Satellite 100CS
PA2711UX (YX)	PORT REPLICATOR	Satellite Pro 410CDT
PA2711UX (YX)	PORT REPLICATOR	Satellite Pro 410CS
PA2712U (E/EY)	DESK STATION	Tecra 700CS/CT
PA2713U	PORT REPLICATOR	Tecra 700CS/CT
PA2713U	PORT REPLICATOR	Tecra 710CDT
PA2713U	PORT REPLICATOR	Tecra 720CDT
PA2800U	i486DX2-50 CPU UPGRADE	T6400 series
PA2801U	HOLDING STAND	T100X
PA2803U	TURBO CACHE	T6600C
PA2805U	BALL POINT MOUSE	T1900S
PA2807U	SOUND CARD	T2400CS
PA2807U	SOUND CARD	T2400CT
PA2807U	SOUND CARD	T2450CT
PA5355U	EXPANSION HDD (100MB)	T8500
PA7132U	384KB MEMORY KIT	T1100+
PA7134U	768KB MEMORY KIT	T1000
PA7135E	2MB MEMORY KIT	T3100
PA7137U	3MB MEMORY KIT	T3200
PA7139U	1MB EMS KIT	T1200
PA7225U V (E V)	5" FDD UNIT	T1600
PA7225U (E)	5" FDD UNIT	T1000
PA7225U (E)	5" FDD UNIT	T1100+
PA7225U (E)	5" FDD UNIT	T1200
PA7225U (E)	5" FDD UNIT	T3100
PA7225U (E)	5" FDD UNIT	T3200
PA7310U (E)	EXPANSION-BOX	T1100+
PA7310U (E)	EXPANSION-BOX	T1200
PA7310U (E)	EXPANSION-BOX	T3100
PA7312E	EXPANSION-I/F	T1100+
PA7312E	EXPANSION-I/F	T1200
PA7313E	EXPANSION-I/F	T3100
PA7353E	NUMERIC KEYPAD	T3100
PA7353E	NUMERIC KEYPAD	T3100E
PA7354E V	NUMERIC KEYPAD	T1000
PA7354E V	NUMERIC KEYPAD	T1200
PA7354E V	NUMERIC KEYPAD	T1200XE
PA7354E V	NUMERIC KEYPAD	T1600
PA7354E V	NUMERIC KEYPAD	T1800
PA7354E V	NUMERIC KEYPAD	T1850/C
PA7354E V	NUMERIC KEYPAD	T2000
PA7354E V	NUMERIC KEYPAD	T2000SX

PA7354E V	NUMERIC KEYPAD	T2000SXE
PA7354E V	NUMERIC KEYPAD	T2200SX
PA7354E V	NUMERIC KEYPAD	T3100SX
PA7354E V	NUMERIC KEYPAD	T3300SL
PA7354E V	NUMERIC KEYPAD	T4400 series
PA7365U	FLOPPY LINK	T1100+
PA7367E	FLOPPY LINK	T1000
PA7367E	FLOPPY LINK	T1200
PA7367E	FLOPPY LINK	T3100
PA7367E	FLOPPY LINK	T3200
PA7437E	MODEM	T1000
PA7438E	MODEM	T1100+
PA7438E	MODEM	T1200
PA7438E	MODEM	T3100
PA7439E	MODEM	T1200
PA7439E	MODEM	T1600
PA7482U	AC ADAPTER	T1000
PA7482U	AC ADAPTER	T1100+
PA7483U	AUTOMOBILE POWER ADAPTER	T1000
PA7483U	AUTOMOBILE POWER ADAPTER	T1100+
PA7485U (E)	AC ADAPTER	T1200
PA7486U	AUTOMOBILE POWER ADAPTER	T1200
PA7486U	AUTOMOBILE POWER ADAPTER	T1600
PA7487U (E/Y)	AC ADAPTER	T1600
PA7489U	AUTOMOBILE POWER ADAPTER	T3100SX
PA7490U	BATTERY CHARGER	T1200
PA7491U	MAIN BATTERY	T1200
PA7494U	AUTOMOBILE POWER ADAPTER	T1600
PA8301U	2MB MEMORY CARD	T5100
PA8302U	2MB MEMORY KIT	T1600
PA8304U	2MB MEMORY KIT	T5200
PA8304U	2MB MEMORY KIT	T8500
PA8306U	2MB MEMORY KIT	T1200XE
PA8307U	2MB MEMORY KIT	T3200SX
PA8307U	2MB MEMORY KIT	T3200SXC
PA8308U	2MB MEMORY KIT	T3100SX
PA8309U	4MB MEMORY KIT	T3200SX
PA8309U	4MB MEMORY KIT	T3200SXC
PA8310U	4MB MEMORY KIT	T3100SX
PA8311U	1MB MEMORY KIT	T1000LE
PA8311U	1MB MEMORY KIT	T1000SE
PA8311U	1MB MEMORY KIT	T1000XE
PA8312U	2MB MEMORY KIT	T1000LE
PA8312U	2MB MEMORY KIT	T1000SE
PA8312U	2MB MEMORY KIT	T1000XE
PA8313U	8MB MEMORY KIT	T5200
PA8313U	8MB MEMORY KIT	T8500
PA8314U	4MB MEMORY KIT	T1000LE
PA8314U	4MB MEMORY KIT	T2000
PA8314U	4MB MEMORY KIT	T2000SX
PA8315U	8MB MEMORY KIT	T1000LE
PA8315U	8MB MEMORY KIT	T2000
PA8315U	8MB MEMORY KIT	T2000SX
PA8316U	1MB MEMORY KIT	T2000
PA8316U	1MB MEMORY KIT	T2000SX
PA8317U	2MB MEMORY KIT	T2000
PA8317U	2MB MEMORY KIT	T2000SX
PA8340U	512KB MEMORY KIT	T3100E
PA8341U	2MB MEMORY KIT	T3100E
PA8380U	3.5" FDD UNIT	T1000XE
PA8600U (E/Y)	DESK STATION	T1000LE/SE/XE

PA8600U (E/Y)	DESK STATION	T1200XE
PA8600U (E/Y)	DESK STATION	T2000
PA8600U (E/Y)	DESK STATION	T2000SX
PA8600U (E/Y)	DESK STATION	T2000SXE
PA8601U (E/Y)	DESK STATION	T3100SX
PA8701U	AC ADAPTER	T1000
PA8701U	AC ADAPTER	T1100+
PA8702U	BATTERY CHARGER	T1600
PA8703U	MAIN BATTERY	T1600
PA8704U (E/Y)	BATTERY CHARGER	T1000LE/SE/Xe
PA8704U (E/Y)	BATTERY CHARGER	T1200XE
PA8705U	MAIN BATTERY	T1000LE
PA8706U (E)	AC ADAPTER	T1000LE
PA8706U (E)	AC ADAPTER	T1000XE
PA8706U (E)	AC ADAPTER	T1200XE
PA8707U (E/Y)	BATTERY CHARGER	T3100SX
PA8708U	MAIN BATTERY	T3100SX
PA8709U	AC ADAPTER	T3100SX
PA8712U	MAIN BATTERY	T1000LE
PA8712U	MAIN BATTERY	T1000SE
PA8712U	MAIN BATTERY	T1000XE
PA8712U	MAIN BATTERY	T1200XE
PA8715U	MAIN BATTERY	T1600
PA8717U	AUTOMOBILE POWER ADAPTER	T1000LE
PA8718U	101-KEY KEYBOARD ADAPTER	T1800
PA8718U	101-KEY KEYBOARD ADAPTER	T1850/C
PA8718U	101-KEY KEYBOARD ADAPTER	T2000
PA8718U	101-KEY KEYBOARD ADAPTER	T2000SX
PA8718U	101-KEY KEYBOARD ADAPTER	T2000SXE
PA8718U	101-KEY KEYBOARD ADAPTER	T2200SX
PA8718U	101-KEY KEYBOARD ADAPTER	T3100SX
PA8718U	101-KEY KEYBOARD ADAPTER	T3300SL
PA8718U	101-KEY KEYBOARD ADAPTER	T4400 series
PA8719U	OPTIONAL BATTERY	T1000LE
PA8725U	MAIN BATTERY	T2000SX
PA8725U	MAIN BATTERY	T2000SXE
PA8727U (E/Y)	AC ADAPTER	T2000SX/SXE