TandyFax 1000 (430-1200) Setting Fax Parameters Faxback Doc. # 8976

The TANDYFAX 1000 fax machine has a variety of adjustable parameters. You need not change most of the parameters once they are set (like the choice between Tone Dialing and Pulse Dialing).

Some parameters, such as the Resolution or Contrast Parameters, might never need to be changed using this method, since you can temporarily change them using simple key operations just before you send a fax. When the transmission ends, these parameters return to the preset values or values set in the procedure described below.

Other parameters can only be changed by this procedure.

PRESS DISPLAY 1 Function SET MODE (PRESS MODE) 2 MODE FAX PARAMETERS 3 START FAX PARAMETER NO.

4 Enter a two-digit fax parameter number. (Refer to the Fax Parameter Table.) Proceed single-digit parameters with a 0.

Example: 0 1 for RESOLUTION

FAX PARAMETER No. 01 [1]=1

5 Enter the setting number. The number displayed in brackets is the current default setting.

Example: 2 changes the preset resolution to FINE.

6	START
	ENTER

FAX PARAMETER NO.

7 Return to Step 4 to set the next parameter, or press STANDBY/STOP to return to the standby mode.

NOTE: To cancel any digit entered, press CLEAR.

Parameter Table

Parameter Number	Parameter	Setting Number	Setting	Standard Setting
01	Resolution	1 2 3	Standard Fine Super Fine	0
02		1	Normal	0

	Contrast	2 3	Dark Light		
04	Polled	1 2	OFF ON	0	
05	Automatic Journal Print	1 2	Yes No	0	
06	Heading	1 2 3		Print inside copy area O Print outside copy area Not printed	
07	Dialing Method	1 2	Tone Pulse	0	
10	Key Tone (Beep)	1 2	Soft Loud	0	
13	Sending in "No Paper" or "Receiving Er ror" state (See	1	Allowed	0	
	Note.)	2	Not Allowed		

Note: When you set Parameter 13 to 1, you can send documents even when your TandyFax 1000 has no more recording papaer, or when a mechanical error has occurred which affects receiving. Some transactions, however, might not be recorded on the journal when either of these situations occurrs.

(smc-03/02/94)