Inspiron 13 7000 series 2-in-1 Service Manual



Computer Model: Inspiron 13-7368 Regulatory Model: P69G Regulatory Type: P69G001

Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© **2016 Dell Inc. All rights reserved.** This product is protected by U.S. and international copyright and intellectual property laws. Dell and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2016-05

Rev. A01

Contents

Before working inside your computer	
Before you begin	
Safety instructions	
Recommended tools	
After working inside your computer	15
Removing the base cover	16
Procedure	
Replacing the base cover	19
Procedure	
Removing the battery	20
Prerequisites	
Procedure	
Replacing the battery	
Procedure	
Post-requisites	22
Removing the memory modules	23
Prerequisites	23
Procedure	
Replacing the memory modules	
Procedure	
Post-requisites	

Removing the solid-state drive	29
Prerequisites	
Procedure	29
Replacing the solid-state drive	31
Procedure	
Post-requisites	
Removing the coin-cell battery	33
Prerequisites	
Procedure	33
Replacing the coin-cell battery	35
Procedure	35
Post-requisites	35
Removing the wireless card	36
Prerequisites	36
Procedure	
Replacing the wireless card	
Procedure	
Post-requisites	
Removing the keyboard daughter-board	40
Prerequisites	
Procedure	40
Replacing the keyboard daughter-board	42
Procedure	
Post-requisites	42

Removing the speakers	
Prerequisites	
Procedure	
Replacing the speakers	
Procedure	
Post-requisites	
Removing the fan	
Prerequisites	
Procedure	
Replacing the fan	
Procedure	
Post-requisites	
Removing the heat sink	49
Removing the heat sink	
-	
Prerequisites	
Prerequisites Procedure	
Prerequisites Procedure Replacing the heat sink	
Prerequisites Procedure Replacing the heat sink Procedure Post-requisites	
Prerequisites Procedure Replacing the heat sink Procedure	
Prerequisites Procedure Replacing the heat sink Procedure Post-requisites Removing the power-adapter port	49 49 51 51 51 51 52
Prerequisites Procedure Procedure Procedure Post-requisites Removing the power-adapter port Prerequisites	
Prerequisites Procedure Replacing the heat sink Procedure Post-requisites Removing the power-adapter port Prerequisites Procedure	49 49 51 51 51 51 52 52 52 52 52

Removing the power and volume-buttons board	55
Prerequisites	
Procedure	55
Replacing the power and volume-buttons board	57
Procedure	57
Post-requisites	57
Removing the status-light board	58
Prerequisites	58
Procedure	58
Replacing the status-light board	61
Procedure	61
Post-requisites	61
Removing the touch pad	62
Prerequisites	62
Procedure	62
Replacing the touch pad	66
Procedure	66
Post-requisites	66
Removing the I/O board	67
Removing the I/O board.	
•	67
Prerequisites	67 67
Prerequisites Procedure	67 67 69

Removing the display assembly	70
Prerequisites	
Procedure	70
Replacing the display assembly	74
Procedure	74
Post-requisites	74
Removing the system board	75
Prerequisites	75
Procedure	75
Replacing the system board	80
Procedure	80
Post-requisites	81
Entering the Service Tag in the BIOS setup program	81
Removing the keyboard	82
Prerequisites	82
Procedure	83
Replacing the keyboard	86
Procedure	86
Post-requisites	86
Removing the palm rest and keyboard assembly	87
Prerequisites	87
Procedure	87
Replacing the palm rest and keyboard assembly	89
Procedure	
Post-requisites	89

Removing the display panel	
Prerequisites	
Procedure	
Replacing the display panel	93
Procedure	
Post-requisites	
Removing the display back-cover and antenna	
assembly	
Prerequisites	
Procedure	94
Replacing the display back-cover and antenna	
assembly	
Procedure	
Post-requisites	96
Removing the camera	97
Prerequisites	97
Procedure	97
Replacing the camera	99
Procedure	
Post-requisites	99
Removing the display cable	100
Prerequisites	
Procedure	
Replacing the display cable	102
Procedure	
Post-requisites	

Removing the sensor board	103
Prerequisites	
Procedure	103
Replacing the sensor board	105
Procedure	105
Post-requisites	105
Flashing the BIOS	106
Technology and components	107
Audio	107
Downloading the audio driver	107
Identifying the audio controller	107
Changing the audio settings	108
Camera	108
Identifying the webcam in device manager	108
Starting the camera application	108
Getting the Dell Webcam Central	109
Display	110
Adjusting the brightness	110
Changing the screen resolution	110
Rotating the display	111
Cleaning the display	111
HDMI	112
Connecting to external display devices	112
Graphics	114
Downloading the graphics driver	114
Identifying the display adapter	114
Changing the display settings in Intel HD Graphics Control Panel.	115
Intel WiDi	115
Downloading the WiDi application	116

Setting up the wireless display	116
USB	
Downloading the USB 3.0 driver	
Enabling or disabling the USB in BIOS setup program	117
Fixing a no-boot issue caused by USB emulation	
Wi-Fi	118
Turning on or off Wi-Fi	118
Configuring Wi-Fi	
Bluetooth	119
Turning on or off Bluetooth	119
Pairing the Bluetooth-enabled devices	119
Transferring files between devices using Bluetooth	
Removing the Bluetooth device	
Hard Drive	122
Identifying the hard drive	122
Identifying the hard drive in BIOS setup program	
Media-card reader	
Downloading the media-card reader driver	
Keyboard	123
Changing the keyboard language	
Keyboard shortcuts	124
Touch pad	125
Identifying the touch pad	125
Touch pad gestures	126
Power adapter	126
Battery	127
Chipset	127
Downloading the chipset driver	
Identifying the chipset	127
Memory	128
Checking the system memory in Windows	128
Verifying the system memory in BIOS setup program	129
Testing memory using ePSA	129
Processors	129

Identifying the processors in Windows	129
Checking the processor usage in the task manager	130
Operating System	
Service Tag location	
Device drivers	
Intel Dynamic Platform and Thermal Framework	131
Intel Chipset Software Installation Utility	131
Intel HD Graphics 520 driver	132
Intel Serial IO Driver	
Intel Trusted Execution Engine Interface	134
Intel Virtual Button driver	135
Intel Wireless 3165 WiFi and Bluetooth drivers	136
BIOS overview	
Entering the BIOS setup program	
Boot menu	
Boot menu enhancements	137
Timing key sequences	137
System diagnostic lights	138
Getting help and contacting Dell	140
Self-help resources	
Contacting Dell	141

Before working inside your computer

Ø

NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Before you begin

- 1 Save and close all open files and exit all open applications.
- 2 Shut down your computer.

The shut-down instruction varies depending on the operating system installed on your computer.

- Windows 10: Click or tap Start $\rightarrow \bigcirc$ Power \rightarrow Shut down.
- Windows 8.1: On the **Start** screen, click or tap the power icon 0 \rightarrow Shut down
- Windows 7: Click or tap **Start** \rightarrow **Shut down**.



NOTE: If you are using a different operating system, see the documentation of your operating system for shut-down instructions.

- 3 Disconnect your computer and all attached devices from their electrical outlets.
- 4 Disconnect all cables such as telephone cables, network cables, and so on, from your computer.
- 5 Disconnect all attached devices and peripherals, such as keyboard, mouse, monitor, and so on, from your computer.
- 6 Remove any media card and optical disc from your computer, if applicable.

Safety instructions

Use the following safety guidelines to protect your computer from potential damage and ensure your personal safety.



WARNING: Before working inside your computer, read the safety information that shipped with your computer. For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory compliance.



WARNING: Disconnect all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting to the electrical outlet.



CAUTION: To avoid damaging the computer, ensure that the work surface is flat and clean.



CAUTION: To avoid damaging the components and cards, handle them by their edges, and avoid touching pins and contacts.



 \bigwedge CAUTION: You should only perform troubleshooting and repairs as authorized or directed by the Dell technical assistance team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. See the safety instructions that shipped with the product or at www.dell.com/regulatory_compliance.



CAUTION: Before touching anything inside your computer, ground yourself by touching an unpainted metal surface, such as the metal at the back of the computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity, which could harm internal components.





CAUTION: Press and eject any installed card from the media-card reader.

Recommended tools

The procedures in this document may require the following tools:

Phillips screwdriver

• Plastic scribe

After working inside your computer



CAUTION: Leaving stray or loose screws inside your computer may severely damage your computer.

- 1 Replace all screws and ensure that no stray screws remain inside your computer.
- 2 Connect any external devices, peripherals, or cables you removed before working on your computer.
- **3** Replace any media cards, discs, or any other parts that you removed before working on your computer.
- 4 Connect your computer and all attached devices to their electrical outlets.
- **5** Turn on your computer.

Removing the base cover

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

1 Close the display and turn the computer over.

2 Remove the screws that secure the base cover to the palm-rest assembly.



Using a plastic scribe, release the tabs that secure the base cover to the palm-rest assembly and remove the base cover off the palm-rest assembly.



3 base cover

Replacing the base cover

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Align the base cover with the palm-rest assembly and snap it into place.
- 2 Replace the screws that secure the base cover to the palm-rest assembly.

Removing the battery

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

Remove the base cover.

Procedure

- 1 Disconnect the battery cable from the system board.
- 2 Remove the screws that secure the battery to the palm-rest assembly.

3 Lift the battery off the palm-rest assembly.



- 1 system board
- 3 screws (4)
- 5 battery

- 2 battery cable
- 4 palm-rest assembly
- 4 Press and hold the power button for five seconds to ground the system board.

Replacing the battery

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Align the screw holes on the battery with the screw holes on the palmrest assembly.
- 2 Replace the screws that secure the battery to the palm-rest assembly.
- **3** Connect the battery cable to the system board.

Post-requisites

Replace the base cover.

Removing the memory modules

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

1 Lift the Mylar to access the memory module.



2 Use your fingertips to carefully spread apart the securing-clips on each end of the memory-module slot until the memory module pops up.

3 Remove the memory module from the memory-module slot.



- 1 securing clips (2)
- 3 memory-module slot
- 2 memory module

Replacing the memory modules

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Lift the Mylar to access the memory-module slot.
- 2 Align the notch on the memory module with the tab on the memorymodule slot.

3 Slide the memory module firmly into the slot at an angle and press the memory module down until it clicks into place.



NOTE: If you do not hear the click, remove the memory module and reinstall it.



- 1 memory module
- 3 notch
- 5 Mylar

Post-requisites

1 Replace the <u>battery</u>.

- 2 memory-module slot
- 4 tab

2 Replace the <u>base cover</u>.

Removing the solid-state drive

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.



CAUTION: Solid-state drives are fragile. Exercise care when handling the solid-state drive.

CAUTION: To avoid data loss, do not remove the solid-state drive while the computer is in sleep or on state.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the battery.

Procedure

1 Remove the screw that secures the solid-state drive to the palm-rest assembly.

2 Slide and remove the solid-state drive off the system board.



- 1 screw
- 3 solid-state drive slot
- 5 palm-rest assembly
- 2 solid-state drive
- 4 system board

Replacing the solid-state drive

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in Before working inside your computer. After working inside your computer, follow the instructions in After working inside your computer. For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.



CAUTION: Solid-state drives are fragile. Exercise care when handling the solid-state drive.

Procedure

1 Slide the solid-state drive firmly into the slot on the system board at an angle and gently press the solid-state drive down until it snaps into position.



NOTE: Ensure that the solid-state drive is firmly seated.

2 Press the other end of the solid-state drive and replace the screw that secures the solid-state drive to the palm-rest assembly.



- 1 screw
- 3 solid-state drive slot
- 5 palm-rest assembly

Post-requisites

- **1** Replace the <u>battery</u>.
- 2 Replace the <u>base cover</u>.

- 2 solid-state drive
- 4 system board

Removing the coin-cell battery

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.



CAUTION: Removing the coin-cell battery resets the BIOS setup program's settings to default. It is recommended that you note the BIOS setup program's settings before removing the coin-cell battery.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

1 Disconnect the coin-cell battery cable from the I/O board.

2 Peel the coin-cell battery off the palm-rest assembly.



- 1 I/O board
- 3 coin-cell battery

- 2 coin-cell battery cable
- 4 palm-rest assembly

Replacing the coin-cell battery

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Adhere the coin-cell battery to the palm-rest assembly.
- 2 Connect the coin-cell battery cable to the I/O board.

Post-requisites

- 1 Replace the <u>battery</u>.
- 2 Replace the <u>base cover</u>.

Removing the wireless card

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

- 1 Remove the screw that secures the wireless-card bracket to the wireless card.
- 2 Disconnect the antenna cables from the wireless card.
3 Slide and remove the wireless card from the wireless-card slot.



- 1 screw
- 3 wireless-card slot
- 5 antenna cables (2)

- 2 wireless-card bracket
- 4 wireless card

Replacing the wireless card

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure



CAUTION: To avoid damage to the wireless card, do not place any cables under it.

- 1 Align the notch on the wireless card with the tab on the wireless-card slot.
- 2 Insert the wireless card at an angle into the wireless-card slot.
- **3** Connect the antenna cables to the wireless card.

The following table provides the antenna-cable color scheme for the wireless card supported by your computer.

Connectors on the wireless card	Antenna-cable color	
Main (white triangle)	White	
Auxiliary (black triangle)	Black	

4 Align the screw hole on the wireless card bracket with the screw hole on the wireless card.

5 Replace the screw that secures the wireless card bracket to the wireless card.



- 1 Replace the <u>battery</u>.
- 2 Replace the <u>base cover</u>.

Removing the keyboard daughter-board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

1 Open the latches and disconnect the keyboard cable, keyboard daughter-board cable, keyboard-backlight cable, touch-pad cable, and status-light board-cable from the keyboard daughter-board.

2 Using a plastic scribe, pry the keyboard daughter-board off the palm-rest assembly.



- 1 keyboard cable
- 3 palm-rest assembly
- 5 keyboard daughter-board cable
- 7 status-light board-cable
- 9 keyboard daughter-board

- 2 keyboard-backlight cable
- 4 touch-pad cable
- 6 latch
- 8 plastic scribe

Replacing the keyboard daughter-board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Adhere the keyboard daughter board on the palm-rest assembly.
- 2 Connect the keyboard cable, keyboard daughter-board cable, keyboardbacklight cable, touch-pad cable, and status-light board-cable and close the latches to secure the cables.

- 1 Replace the <u>battery</u>.
- 2 Replace the base cover.

Removing the speakers

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

- 1 Disconnect the speaker cable from the system board.
- 2 Peel off the pieces of tape that secure the speaker cable to the palm-rest assembly.
- **3** Remove the speaker cable from the routing guides on the palm-rest assembly.
- 4 Note the position of the rubber grommets before lifting the speaker.

5 Remove the speakers from the alignment posts and lift the speakers off the palm-rest assembly.



7 speakers (2)

8 rubber grommets (5)

Replacing the speakers

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure



NOTE: The rubber grommets may get pushed out while replacing the speaker. Ensure that the rubber grommets are in their position after placing the speaker on the palm-rest assembly.

- 1 Using the alignment posts, align and place the speakers on the palm-rest assembly.
- 2 Replace the rubber grommets if they are pushed up while replacing the speaker.
- **3** Route the speaker cable through the routing guides on the palm-rest assembly.
- **4** Adhere the pieces of tape that secure the speaker cable to the palm-rest assembly.
- **5** Connect the speaker cable to the system board.

- **1** Replace the <u>battery</u>.
- 2 Replace the <u>base cover</u>.

Removing the fan

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

- 1 Remove the screws that secure the fan to the palm-rest assembly.
- 2 Disconnect the fan cable from the system board.

3 Move the antenna cables out of the way and lift the fan off the palm-rest assembly.



- 1 antenna cables (2)
- 3 fan
- 5 fan cable

- 2 palm-rest assembly
- 4 screws (2)
- 6 system board

Replacing the fan

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure



 $\Delta_{\rm it.}^{\rm CAUTION:\,To}$ avoid damage to the fan, do not place any cables under

- 1 Align the screw holes on the fan with the screw holes on the palm-rest assembly.
- 2 Replace the screws that secure the fan to the palm-rest assembly.
- **3** Connect the fan cable to the system board.

- **1** Replace the <u>battery</u>.
- 2 Replace the <u>base cover</u>.

Removing the heat sink

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.



WARNING: The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.

CAUTION: For maximum cooling of the processor, do not touch the heat transfer areas on the heat sink. The oils in your skin can reduce the heat transfer capability of the thermal grease.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

1 In sequential order (as indicated on the heat sink), loosen the captive screws that secure the heat sink to the system board.

2 Lift the heat sink off the system board.



1 heat sink

2 captive screws (4)

3 system board

Replacing the heat sink

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.



CAUTION: Incorrect alignment of the heat sink can damage the system board and processor.



NOTE: The original thermal grease can be reused if the original system board and heat sink are reinstalled together. If either the system board or the heat sink is replaced, use the thermal pad provided in the kit to ensure that thermal conductivity is achieved.

Procedure

- 1 Place the heat sink on the system board.
- 2 Align the screw holes on the heat sink with the screw holes on the system board.
- 3 In sequential order (indicated on the heat sink), tighten the captive screws that secure the heat sink to the system board.

- 1 Replace the <u>battery</u>.
- 2 Replace the <u>base cover</u>.

Removing the power-adapter port



Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.

Procedure

- 1 Disconnect the power-adapter port-cable from the system board.
- 2 Remove the screw that secures the power-adapter port to the palm-rest assembly.

3 Lift the power-adapter port off the palm-rest assembly.



- 1 power-adapter port-cable
- 2 screw
- 3 power adapter port
- 5 palm-rest assembly
- 4 system board

Replacing the power-adapter port



Procedure

- 1 Place the power-adapter port into the slot on the palm-rest assembly.
- 2 Align the screw hole on the power-adapter port with the screw hole on the palm-rest assembly.
- **3** Replace the screw that secures the power-adapter port to the palm-rest assembly.
- 4 Connect the power-adapter port-cable to the system board.

- 1 Replace the <u>battery</u>.
- 2 Replace the <u>base cover</u>.

Removing the power and volume-buttons board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the base cover.
- 2 Remove the battery.
- **3** Remove the <u>coin-cell battery</u>.

Procedure

- 1 Peel off the tape that secures the power and volume-buttons boardcable to the palm-rest assembly.
- 2 Disconnect the power and volume-buttons board-cable from the I/O board.
- **3** Remove the power and volume-buttons board-cable from the routing guides on the palm-rest assembly.
- 4 Remove the screw that secures the power and volume-buttons board to the palm-rest assembly.

5 Lift the power and volume-buttons board off the palm-rest assembly.



Replacing the power and volume-buttons board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Align the screw hole on the power and volume-buttons board with the screw hole on the palm-rest assembly.
- 2 Replace the screw that secures the power and volume-buttons board to the palm-rest assembly.
- **3** Route the power and volume-buttons board-cable through the routing guides on the palm-rest assembly.
- 4 Connect the power and volume-buttons board-cable to the I/O board.
- 5 Adhere the tape that secures the power and volume-buttons board-cable to the palm-rest assembly.

- 1 Replace the <u>coin-cell battery</u>.
- 2 Replace the <u>battery</u>.
- **3** Replace the <u>base cover</u>.

Removing the status-light board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the base cover.
- 2 Remove the <u>battery</u>.

Procedure

- **1** Peel off the pieces of tape securing the speaker cable to the palm-rest assembly.
- 2 Remove the speaker cable from the routing guides on the palm-rest assembly.

3 Lift the speaker cable off the status-light board.



- 3 speaker cable
- 4 Open the latch and disconnect the status-light board-cable from the keyboard daughter-board.
- **5** Peel the foam securing the status-light board to the palm-rest assembly.

6 Lift the status-light board off the palm-rest assembly.



- latch 1
- 3 keyboard daughter-board
- 2 status-light board-cable
- 4
- 5 foam

status-light board

Replacing the status-light board



Procedure

- 1 Align and place the status-light board in the slot on the palm-rest assembly.
- 2 Adhere the foam securing the status-light board to the palm-rest assembly.
- **3** Slide the status-light board-cable into the connector on the keyboard daughter-board and close the latch to secure the cable.
- **4** Adhere the pieces of tape securing the speaker cable to the palm-rest assembly.

- **1** Replace the <u>battery</u>.
- 2 Replace the base cover.

Removing the touch pad

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- **3** Remove the <u>status-light board</u>.

Procedure

1 Open the latches and disconnect the keyboard daughter-board cable from the keyboard daughter-board and the system board.

2 Open the latches and disconnect the touch-pad cable from the touch-pad assembly and the keyboard daughter-board.



- 1 system board
- 3 latch
- 5 keyboard daughter-board
- 2 keyboard daughter-board cable
- 4 touch-pad cable
- 6 palm-rest assembly
- **3** Peel off the pieces of tape that secure the touch-pad to the palm-rest assembly.
- **4** Remove the screws that secure the touch-pad bracket to the palm-rest assembly.

5 Lift the touch-pad bracket off the palm-rest assembly.



6 Remove the screws that secure the touch pad to the palm-rest assembly.

7 Lift the touch pad off the palm-rest assembly.



- 1 screws (4) 2 palm-rest assembly
- 3 touch pad

Replacing the touch pad

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Place the touch pad on the palm-rest assembly.
- 2 Align the screw holes on the touch pad with the screw holes on the palm-rest assembly.
- **3** Replace the screws that secure the touch pad to the palm-rest assembly.
- 4 Align the screw holes on the touch-pad bracket with the screw holes on the palm-rest assembly.
- **5** Replace the screws that secure the touch-pad bracket to the palm-rest assembly.
- 6 Adhere the pieces of tape that secure the touch pad to the palm-rest assembly.
- 7 Slide both ends of the touch-pad cable into their respective connectors on the touch pad and keyboard daughter-board and close the latches to secure the cable.
- 8 Slide the keyboard daughter-board cable into their respective connectors on the system board and keyboard daughter-board and close the latches to secure the cable.

- 1 Replace the <u>status-light board</u>.
- 2 Replace the <u>battery</u>.
- **3** Replace the <u>base cover</u>.

Removing the I/O board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- **3** Remove the <u>wireless card</u>.

Procedure

- **1** Peel off the tape that secures the I/O-board cable to the I/O board.
- 2 Disconnect the I/O-board cable from the I/O board.
- **3** Peel off the tape that secures the power and volume-buttons board-cable to the palm-rest assembly.
- 4 Disconnect the power and volume-buttons board-cable from the I/O board.
- 5 Disconnect the coin-cell battery-cable from the I/O board.
- 6 Remove the screws that secures the I/O board to the palm-rest assembly.

7 Lift the I/O board off the palm-rest assembly.



1	I/O board	2	tape
3	I/O-board cable	4	screws (2)
5	palm-rest assembly	6	latch
7	coin-cell battery-cable	8	tape

9 power and volume-buttons board-cable

Replacing the I/O board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Place the I/O board on the palm-rest assembly.
- 2 Align the screw hole on the I/O board with the screw hole on the palmrest assembly.
- **3** Replace the screw that secure the I/O board to the palm-rest assembly.
- 4 Connect the power and volume-buttons board-cable and coin-cell battery-cable to the I/O board.
- 5 Connect the I/O-board cable to the I/O board.
- 6 Adhere the tape that secures the power and volume-buttons board-cable to the palm-rest assembly.
- 7 Adhere the tape that secures the I/O-board cable to the I/O board.

- **1** Replace the <u>wireless card</u>.
- 2 Replace the <u>battery</u>.
- **3** Replace the <u>base cover</u>.

Removing the display assembly



Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the battery.
- **3** Remove the <u>wireless card</u>.

Procedure

1 Peel off the pieces of tape that secure the display cable and touch-screen board-cable to the system board.

2 Open the latches to disconnect the display cable and the touch-screen board-cable from the system board.



3 Turn the computer over and open the display as far as possible.

CAUTION: Place the computer on a soft and clean surface to avoid scratching the display.

4 Place the computer face down on a flat surface.

5 Remove the screws that secure the display assembly to the palm-rest assembly.



3 display hinges (2)

4 palm-rest assembly
6 Lift the display assembly off the palm-rest assembly.



1 display assembly

Replacing the display assembly

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure



CAUTION: Place the computer on a soft and clean surface to avoid scratching the display.

- 1 Place the display assembly face down on the palm-rest assembly.
- 2 Align the screw holes on the display hinges with the screw holes on the palm-rest assembly.
- **3** Replace the screws that secure the display assembly to the palm-rest assembly.
- 4 Close the display and turn the computer over.
- **5** Slide the display cable and the touch-screen board-cable into their respective connectors on the system board and close the latches to secure the cables.
- 6 Adhere the pieces of tape that secure the display cable and the touchscreen board-cable to their respective connectors on the system board.

- 1 Replace the <u>wireless card</u>.
- 2 Replace the <u>battery</u>.
- 3 Replace the base cover.

Removing the system board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.



NOTE: Your computer's Service Tag is stored in the system board. You must enter the Service Tag in the BIOS setup program after you replace the system board.



NOTE: Replacing the system board removes any changes you have made to the BIOS using the BIOS setup program. You must make the appropriate changes again after you replace the system board.



NOTE: Before disconnecting the cables from the system board, note the location of the connectors so that you can reconnect the cables correctly after you replace the system board.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- **3** Remove the <u>memory modules</u>.
- 4 Remove the <u>fan</u>.
- 5 Remove the <u>heat sink</u>.
- 6 Remove the <u>solid-state drive</u>.

Procedure

1 Peel off the pieces of tape that secure the display cable and touch-screen board-cable to the system board.

2 Peel off the tape that secures the I/O-board cable to the system board.



1 I/O-board cable

2 display cable

- 3 tape (3)
- 5 system board

- 4 touch-screen cable
- **3** Open the latches to disconnect the display cable and the touch-screen board-cable from the system board.
- 4 Open the latch to disconnect the I/O-board cable from the system board.
- **5** Disconnect the power-adapter cable and the speaker cable from the system board.

6 Open the latch and disconnect the keyboard daughter-board cable from the system board.



7 Remove the screws that secure the system-board bracket to the system board and the palm-rest assembly.

9

tape

8 Lift the system-board bracket off the palm-rest assembly.



- 1 screws (2)
- 3 system board

- 2 system-board bracket
- 4 palm-rest assembly
- **9** Remove the screws that secure the system board to the palm-rest assembly.

10 Lift the system board off the palm-rest assembly.



1 screw (3)

- 2 system board
- 3 palm-rest assembly

Replacing the system board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.



NOTE: Your computer's Service Tag is stored in the system board. You must enter the Service Tag in the BIOS setup program after you replace the system board.



NOTE: Replacing the system board removes any changes you have made to the BIOS using the BIOS setup program. You must make the appropriate changes again after you replace the system board.

Procedure

- 1 Align the screw holes on the system board with the screw holes on the palm-rest assembly.
- 2 Replace the screw that secures the system board to the palm-rest assembly.
- **3** Align the screw holes on the system-board bracket with the screw holes on the system board and the palm-rest assembly.
- 4 Replace the screws that secure the system-board bracket to the system board and the palm-rest assembly.
- **5** Slide the I/O-board cable into the connector on the system board and close the latch to secure the cable.
- 6 Adhere the tape that secures the I/O-board cable to the system board.
- 7 Connect the power-adapter port-cable and the speaker cable to the system board.
- 8 Slide the keyboard daughter-board cable into the connector on the system board and close the latch to secure the cable.
- **9** Slide the display cable and the touch-screen board-cable into their respective connectors close the latches to secure the cables.
- **10** Adhere the pieces of tapes that secure the display cable and touch-screen board-cable to the system board.

Post-requisites

- **1** Replace the <u>solid-state drive</u>.
- 2 Replace the heat sink
- **3** Replace the <u>fan</u>.
- 4 Replace the <u>memory modules</u>.
- 5 Replace the <u>battery</u>.
- 6 Replace the <u>base cover</u>.

Entering the Service Tag in the BIOS setup program

- **1** Turn on or restart your computer.
- 2 Press F2 when the Dell logo is displayed to enter the BIOS setup program.
- 3 Navigate to the **Main** tab and enter the Service Tag in the **Service Tag** Input field.

Removing the keyboard

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- **3** Remove the <u>memory modules</u>.
- 4 Remove the <u>solid-state drive</u>.
- 5 Remove the <u>wireless card</u>.
- 6 Remove the <u>fan</u>.
- 7 Remove the <u>display assembly</u>.
- 8 Remove the heat sink.
- 9 Remove the <u>I/O board</u>.
- **10** Remove the <u>power-adapter port</u>.
- **11** Remove the <u>system board</u>.

Procedure

1 Lift the speaker off the palm-rest assembly.



- 1 speaker cable 2 speaker
- **2** Remove the screws that secure the keyboard shield to the palm-rest assembly.

3 Lift the keyboard shield off the keyboard.



- 1 keyboard shield 2 screws (14)
- Open the latches and disconnect the keyboard cable and keyboard-4 backlight cable (optional) from the system board.



NOTE: The keyboard-backlight cable is present only if the laptop shipped with a backlit keyboard.

5 Lift the keyboard, along with the cables, off the palm-rest assembly.



- 1 keyboard
- 3 screws (14)
- 5 latch

- 2 palm-rest assembly
- 4 keyboard cable
- 6 keyboard backlight-cable

Replacing the keyboard

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Place the keyboard on the palm-rest assembly.
- 2 Align the screw holes on the keyboard with the screw holes on the palmrest assembly.
- **3** Slide the keyboard cable and the keyboard-backlight cable (optional) into the respective connectors and close the latches to secure the cables.
- 4 Replace the screws that secure the keyboard to the palm-rest assembly.
- 5 Align the screw holes on the keyboard shield with the screw holes on the palm-rest assembly.
- 6 Replace the screws that secure the keyboard shield to the palm-rest assembly.

- 1 Replace the <u>system board</u>.
- 2 Replace the <u>power-adapter port</u>.
- **3** Replace the <u>I/O board</u>.
- 4 Replace the heat sink.
- 5 Replace the <u>display assembly</u>.
- 6 Replace the <u>fan</u>.
- 7 Replace the <u>wireless card</u>.
- 8 Replace the <u>solid-state drive</u>.
- 9 Replace the <u>memory modules</u>.
- **10** Replace the <u>battery</u>.
- **11** Replace the <u>base cover</u>.

Removing the palm rest and keyboard assembly

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the base cover.
- 2 Remove the <u>battery</u>.
- 3 Remove the <u>memory modules</u>.
- 4 Remove the <u>coin-cell battery</u>.
- 5 Remove the <u>solid-state drive</u>.
- 6 Remove the <u>wireless card</u>.
- 7 Remove the <u>fan</u>.
- 8 Remove the <u>touch pad</u>.
- 9 Remove the <u>display assembly</u>.
- **10** Remove the <u>heat sink</u>.
- **11** Remove the <u>I/O board</u>.
- **12** Remove the <u>keyboard daughter-board</u>.
- **13** Remove the <u>power-adapter port</u>.
- 14 Remove the power and volume-buttons board.
- **15** Remove the <u>status light board</u>.
- 16 Remove the <u>speakers</u>.
- 17 Remove the <u>system board</u>.
- 18 Remove the keyboard.

Procedure

After performing the steps in prerequisites we are left with the palm-rest and keyboard assembly.



1 palm rest

Replacing the palm rest and keyboard assembly

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

Place the palm-rest and keyboard assembly on a flat surface with the keyboard facing down.

- **1** Replace the <u>keyboard</u>.
- 2 Replace the system board.
- **3** Replace the <u>speakers</u>.
- 4 Replace the status light board.
- 5 Replace the power and volume-buttons board.
- 6 Replace the <u>power-adapter port</u>.
- 7 Replace the <u>keyboard daughter-board</u>.
- 8 Replace the <u>I/O board</u>.
- 9 Replace the heat sink.
- **10** Replace the <u>display assembly</u>.
- **11** Replace the <u>touch pad</u>.
- 12 Replace the <u>fan</u>.
- 13 Replace the <u>wireless card</u>.
- **14** Replace the <u>solid-state drive</u>.
- **15** Replace the <u>coin-cell battery</u>.
- **16** Replace the <u>memory modules</u>.
- **17** Replace the <u>battery</u>.
- **18** Replace the <u>base cover</u>.

Removing the display panel

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- 3 Remove the <u>display assembly</u>.

Procedure

1 Remove the display cable from the routing guides inside the hinge covers.

2 Using a plastic scribe, pry the display-panel assembly off the display back-cover and antenna assembly.



- **3** Turn over the display-panel assembly.
- 4 Remove the <u>camera</u>.

5 Remove the <u>sensor board</u>.

After performing the above steps, we are left with the display panel.



1 display panel

Replacing the display panel

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- **1** Place the display panel on a flat surface.
- 2 Replace the <u>sensor board</u>.
- **3** Replace the <u>camera</u>.
- 4 Turn over the display-panel assembly.
- **5** Route the display cable through the routing guides inside the hinge covers.
- 6 Align the display-panel assembly with the display back-cover and antenna assembly and gently snap the display-panel assembly into place.

- 1 Replace the <u>display assembly</u>.
- 2 Replace the <u>battery</u>.
- 3 Replace the base cover.

Removing the display backcover and antenna assembly

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- **3** Remove the <u>display assembly</u>.
- 4 Follow the procedure from step 1 to step 2 in "<u>Removing the display</u> panel".

Procedure

After performing the steps in prerequisites we are left with the display backcover and antenna assembly.



1 display back-cover and antenna 2 antenna cables assembly

Replacing the display backcover and antenna assembly

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

Place the display back-cover and antenna assembly on a flat surface.

- 1 Replace the <u>display panel</u>.
- 2 Replace the <u>display assembly</u>.
- **3** Replace the <u>battery</u>.
- 4 Replace the <u>base cover</u>.

Removing the camera

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- 3 Remove the <u>display assembly</u>.
- 4 Follow the procedure from step 1 to step 3 in "<u>Removing the display</u> panel".

Procedure



CAUTION: Place the display-panel assembly on a soft and clean surface to avoid scratching the display.

1 Using a plastic scribe, pry the camera module off the display panel.

2 Turn the camera over and peel off the tape to disconnect the camera cable from the camera module.



- 1 display panel
- 3 camera module
- 5 tape

- 2 plastic scribe
- 4 camera cable

Replacing the camera

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Connect the camera cable to the camera module.
- 2 Adhere the tape that secures the camera cable to the camera module.
- **3** Using the alignment post place the camera module on the display panel and snap it into place.

- 1 Follow the procedure from step 4 to step 6 in "<u>Replacing the display</u> panel".
- 2 Replace the <u>display assembly</u>.
- **3** Replace the <u>battery</u>.
- 4 Replace the <u>base cover</u>.

Removing the display cable

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- **3** Remove the <u>display assembly</u>.
- 4 Follow the procedure from step 1 to step 3 in "<u>Removing the display</u> panel".
- 5 Remove the <u>camera</u>.

Procedure

- 1 Peel off the tape and open the latch to disconnect the display cable from the display panel.
- 2 Peel off the sensor-board cable tape and disconnect the sensor-board cable.
- **3** Open the connector latch and disconnect the display cable.
- 4 Note the display cable routing and remove the display cable from the routing guides on the display panel.

5 Lift the display cable off the display panel.



- 1 tape
- 3 sensor-board cable
- 5 latch

- 2 sensor-board cable tape
- 4 display cable
- 6 display panel

Replacing the display cable

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- **1** Route the display cable through the routing guides on the display panel.
- 2 Slide the display cable into the connector and press down the latch to secure the cable.
- **3** Slide the sensor-board cable into the connector on the sensor board and press down the latch to secure the cable.
- 4 Adhere the sensor-board cable tape.
- **5** Adhere the tape that secures the display cable to the display panel.

- 1 Follow the procedure from step 4 to step 6 in "<u>Replacing the display</u> <u>panel</u>".
- 2 Replace the <u>display assembly</u>.
- **3** Replace the <u>camera</u>.
- 4 Replace the battery.
- 5 Replace the <u>base cover</u>.

Removing the sensor board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Prerequisites

- 1 Remove the <u>base cover</u>.
- 2 Remove the <u>battery</u>.
- **3** Remove the <u>display assembly</u>.
- 4 Follow the procedure from step 1 to step 3 in "<u>Removing the display</u> panel".

Procedure



CAUTION: Place the display-panel assembly on a soft and clean surface to avoid scratching the display.

- 1 Remove the screw that secures the sensor board to the display panel.
- 2 Peel off the tape and open the latch to disconnect the sensor-board cable from the sensor board.

3 Lift the sensor board off the display panel.



- 1 sensor board
- 3 tape

5

latch

- 2 screw
- 4 sensor-board cable

Replacing the sensor board

WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before working inside your computer</u>. After working inside your computer, follow the instructions in <u>After working inside your</u> <u>computer</u>. For more safety best practices, see the Regulatory Compliance home page at <u>www.dell.com/regulatory_compliance</u>.

Procedure

- 1 Align the screw hole on the sensor board to the display panel and snap the sensor board in place.
- 2 Slide the sensor-board cable into the slot on sensor board and press down the latch to secure the cable.
- **3** Adhere the tape on the sensor-board connector to secure the cable.
- 4 Replace the screw that secures the sensor board to the display panel.

- 1 Follow the procedure from step 4 to step 6 in "<u>Replacing the display</u> <u>panel</u>".
- 2 Replace the <u>display assembly</u>.
- **3** Replace the <u>battery</u>.
- 4 Replace the <u>base cover</u>.

Flashing the BIOS

You may need to flash (update) the BIOS when an update is available or when you replace the system board. To flash the BIOS:

- 1 Turn on your computer.
- 2 Go to www.dell.com/support.
- 3 Click or tap **Product support**, enter the Service Tag of your computer, and then click or tap Submit.



NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- Click or tap **Drivers & downloads** \rightarrow Find it myself. 4
- 5 Select the operating system installed on your computer.
- 6 Scroll down the page and expand **BIOS**.
- 7 Click or tap **Download** to download the latest version of the BIOS for your computer.
- 8 After the download is complete, navigate to the folder where you saved the BIOS update file.
- 9 Double-click or double-tap the BIOS update file icon and follow the instructions on the screen.

Technology and components

Audio

The Inspiron 13-7368 is shipped with Realtek ALC3253 with Waves MaxxAudio Pro, which is the utility to adjust various audio settings.



NOTE: The audio drivers are already installed when you receive your computer.

Downloading the audio driver

- **1** Turn on your computer.
- 2 Go to <u>www.dell.com/support</u>.
- **3** Click or tap **Product Support**, enter the Service Tag of your computer, and then click or tap **Submit**.



NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- 4 Click or tap Drivers & Downloads → Find it myself.
- 5 Scroll down the page and expand Audio.
- 6 Click or tap **Download** to download the audio driver for your computer.
- 7 After the download is complete, navigate to the folder where you saved the audio driver file.
- 8 Double-click or double-tap the audio driver file icon and follow the instructions on the screen to install the driver.

Identifying the audio controller

- 1 On the taskbar, click or tap the search box, and then type Device Manager.
- Click or tap Device Manager.
 The Device Manager window is displayed.

3 Expand Sound, video and game controllers to view the audio controller.

Before Installation	After Installation
 Sound, video and game controllers Intel High Definition Audio Realtek High Definition Audio(SST) 	 Sound, video and game controllers Intel(R) Display Audio Realtek High Definition Audio(SST)

Changing the audio settings

- 1 On the taskbar, click or tap the search box, and then type Dell Audio.
- 2 Click or tap **Dell Audio** and change the audio settings as required.

Camera

The Inspiron 13-7368 is shipped with an integrated 0.92 megapixel highspeed camera with a maximum of 1280 X 720 HD resolution at 30 FPS. The camera has built-in digital-array microphones.



NOTE: You must replace the camera module if you encounter any issues with the built-in microphones.

Infrared camera - Allows you to video chat, capture photos, and record videos. Depth-sensing feature of the camera enhances security when paired with Windows Hello.

Identifying the webcam in device manager

- 1 On the taskbar, click or tap the search box, and then type Device Manager.
- 2 Click or tap **Device Manager**.

The Device Manager window is displayed.

3 Expand Imaging Devices.

```
✓ → Imaging devices
→ Integrated Webcam
```

Starting the camera application

1 On the taskbar, click or tap the search box, and then type Camera.
2 Click or tap Camera.



Getting the Dell Webcam Central

A CD is shipped along with your computer, which contains the Dell Webcam Central software. If you do not have the software, you can download it by registering through My Account on the Dell website.



NOTE: The Dell Webcam Central is not available for download from the support site or the resource CD.

Display

The Inspiron 13-7368 is shipped with the following display options:

- 13.3-inch HD WLED touch with 1366 X 768 resolution
- 13.3-inch FHD WLED touch screen with 1920 X 1080 resolution

Adjusting the brightness

- 1 Right-click or touch and hold on your desktop and select **Display** settings.
- 2 Drag or swipe the Adjust brightness level slider to adjust the brightness.

← Settings		[- 0	×
SYSTEM		Find a setting		2
Display	1			
Notifications & actions				
Apps & features				
Multitasking				
Tablet mode	Identify Detect Connect to a wireless display Change the size of text, apps, and other items: 150% (Recommended)			
Battery saver				
Power & sleep	Orientation Landscape V			
Storage				
Offline maps	Lock rotation of this display On On			
Default apps	Adjust brightness level			
About	Apply Cancel			
	Advanced display settings			
📑 🔘 I'm Cortana. Ask me anything.	o e 🚍 🚊 🌣	^ \$0 % 40	P = 6	18 AM 4/2016

You can press F11 to decrease brightness and F12 to increase brightness.

Changing the screen resolution

- 1 Right-click or touch and hold on your desktop and select **Display** settings.
- 2 Click or tap Advanced display settings.
- **3** Select the appropriate resolution from the drop-down list.

4 Click or tap Apply.

Settings ADVANCED DISPLAY SETTINGS				- 0	x x
ADVANCED DISPLAY SETTINGS					
		() () () () () () () () () ()			
1					
Identify Detect Connect to a wireless display					
Resolution 1920 × 1080 (Recommended) V					
Apply Cancel					
E O I'm Cortana. Ask me anything.	o e 🗔 i	â <u>°</u>	^ ∎ % 40 ₽ I		1:42 AM 3/9/2016

Rotating the display

- **1** Right-click or touch and hold on your desktop.
- 2 Select Graphics Options \rightarrow Rotation and select from the following options:



The display can also be rotated using the following key combinations:

- Ctrl + Alt + Up arrow key (Rotate to 0 Degrees)
- Ctrl + Alt + Right arrow key (Rotate to 90 Degrees)
- Ctrl + Alt + Down arrow key (Rotate to 180 Degrees)
- Ctrl + Alt + Left arrow key (Rotate to 270 Degrees)

Cleaning the display



CAUTION: Do not use substances such as alcohol, chemicals, or household cleaners for cleaning the display.



CAUTION: To avoid damaging the display, do not apply force when cleaning and wipe off any remaining liquid after cleaning.



NOTE: A commercial display cleaning kit should be used for cleaning. If unavailable, use a soft, damp microfiber cloth lightly sprayed with distilled water.

- **1** Turn off your computer and display before cleaning.
- **2** Gently wipe the display in circular motions to remove any dust or dirt particles.
- **3** Let the display dry thoroughly before turning it on.

HDMI

The Inspiron 13-7368 supports HDMI to connect a TV or another HDMI-in enabled device. It provides video and audio output. The HDMI port is located on the left side of your computer.



NOTE: Appropriate converters (sold separately) are required to connect standard DVI and DisplayPort devices.

Connecting to external display devices

- 1 Connect the HDMI cable to your computer and the external display.
- 2 Press F8 to display different modes.

- 3 Select one of the following display modes:
 - PC screen only
 - Duplicate
 - Extend
 - Second screen only

NOTE: For more information, see the document that shipped with your display device.

Project	
g	PC screen only
gC	Duplicate
ZD	Extend
	Second screen only
Connect to a wi	reless display

Graphics

The Inspiron 13-7368 is shipped with the following video controllers:

- Intel HD Graphics 510 Intel Celeron and Pentium (Shared system memory)
- Intel HD Graphics 520 Intel Core i3/i5/i7 (Shared system memory)
- Intel Iris Graphics 540 Intel Core i7 (Shared system memory)

Downloading the graphics driver

- **1** Turn on your computer.
- 2 Go to <u>www.dell.com/support</u>.
- **3** Click or tap **Product Support**, enter the Service Tag of your computer, and then click or tap **Submit**.



NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- 4 Click or tap **Drivers & downloads** → **Find it myself**.
- 5 Scroll down the page and expand Video.
- 6 Click or tap **Download** to download the graphics driver for your computer.
- 7 After the download is complete, navigate to the folder where you saved the graphics driver file.
- 8 Double-click or double-tap the graphics driver file icon and follow the instructions on the screen to install the driver.

Identifying the display adapter

- 1 On the taskbar, click or tap the search box, and then type Device Manager.
- 2 Click or tap **Device Manager**.

The **Device Manager** window is displayed.

3 Expand **Display adapters**.

Display adapters
 Intel(R) HD Graphics 520

Changing the display settings in Intel HD Graphics Control Panel

1 Right-click or touch and hold on the desktop and select **Graphics Properties** to launch the **Intel HD Graphics Control Panel**.



- 2 Click or tap **Display**.
- **3** Change the display settings as required.

Intel WiDi

The wireless display feature allows you to share your computer display with a compatible TV without using cables. You must connect a wireless display adapter to your TV before setting up the wireless display. To check if your TV supports this feature, see the documentation that is shipped with the TV.

The following table provides the basic system requirements for a wireless display.

Processor	2nd generation Intel Core i3, i5, i7
Video Controller	Intel HD Graphics
WLAN card	Intel 2230 or Intel 6150

Windows 7 or later Operating System Driver Download and install the latest driver for "Intel Wireless Display Connection Manager" available at www.dell.com/

support

Downloading the WiDi application

- 1 Turn on your computer.
- 2 Go to www.dell.com/support.
- 3 Click or tap **Product Support**, enter the Service Tag of your computer, and then click or tap Submit.



NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- Click or tap **Drivers & downloads** → Find it myself. 4
- 5 Scroll down the page and expand Video.
- 6 Click or tap **Download** to download the Intel WiDi application for your computer.
- 7 After the download is complete, navigate to the folder where you saved the WiDi application file.
- 8 Double-click or double-tap the application icon and follow the instructions on the screen to install the application.

Setting up the wireless display

1 Turn on your computer.



NOTE: Ensure that wireless is enabled.

- 2 Connect the wireless display adapter to the TV.
- 3 Turn on the TV and the wireless display adapter.
- 4 Select the appropriate video source for your TV, such as HDMI1, HDMI2, or S-Video.
- 5 Double-click or double-tap the Intel Wireless Display icon on the desktop.

The Intel Wireless Display window is displayed.

- Click or tap Scan for available displays. 6
- 7 Select your wireless display adapter from the **Detected Wireless Displays** list.
- 8 Enter the security code that appears on your TV.

USB

The following table shows the USB ports available in Inspiron 13-7368.

Ports	Location
USB Type-C port	Left side
USB 3.0 port with PowerShare	Left side
USB 2.0 port	Right side



NOTE: USB 3.0 needs the driver to be installed before it can detect any USB devices

Downloading the USB 3.0 driver

- 1 Turn on your computer.
- 2 Go to www.dell.com/support.
- 3 Click or tap **Product Support**, enter the Service Tag of your computer, and then click or tap Submit.



NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- 4 Click or tap **Drivers & Downloads** \rightarrow Find it myself.
- 5 Scroll down the page and expand **Chipset**.
- 6 Click or tap **Download** to download the USB 3.0 driver for your computer.
- 7 After the download is complete, navigate to the folder where you saved USB 3.0 driver file.
- Double-click or double-tap the USB 3.0 driver file icon and follow the 8 instructions on screen to install the driver.

Enabling or disabling the USB in BIOS setup program

- 1 Turn on or restart your computer.
- 2 Press F2 when the Dell logo is displayed on the screen to enter the BIOS setup program.

The BIOS setup program is displayed.

3 On the left pane, select **Settings** \rightarrow **System Configuration** \rightarrow **USB** Configuration.

The USB configuration is displayed on the right pane.

- 4 Select the **Enable External USB Port** check box to either enable or disable it respectively.
- **5** Save the system setup settings and exit.

Fixing a no-boot issue caused by USB emulation

Sometimes the computer does not boot to the operating system when USB devices are connected to the computer during startup. This behavior occurs because the computer is looking for bootable files in the USB devices. Follow these steps to fix the no-boot issue:

- **1** Turn on or restart your computer.
- 2 Press F2 when the Dell logo is displayed on the screen to enter the BIOS setup program.

The BIOS setup program is displayed.

3 On the left pane, select Settings \rightarrow System Configuration \rightarrow USB Configuration.

The USB configuration is displayed on the right pane.

- 4 Clear the **Enable Boot Support** check box to disable it.
- 5 Save the settings and exit.

Wi-Fi

The Inspiron 13-7368 is shipped with Wi-Fi 802.11ac.

Turning on or off Wi-Fi



NOTE: There is no physical switch to enable or disable Wi-Fi. It has to be done through computer settings.

- 1 Swipe-in from the right edge of the display, or click or tap the **Action Center** icon on the task bar to access the Action Center.
- 2 Click or tap **Wi-Fi** to turn Wi-Fi on or off.

Configuring Wi-Fi

- 1 Turn on Wi-Fi. For more information, see <u>Turning on or off Wi-Fi</u>.
- 2 Swipe-in from the right edge of the display, or click or tap the Action **Center** icon on the task bar to access the Action Center.
- **3** Right-click or touch and hold **Wi-Fi**, and then click or tap **Go to settings**. A list of available networks is displayed.

4 Select your network and click or tap **Connect**.





NOTE: Type the network security key if prompted.

Bluetooth

The Inspiron 13-7368 is shipped with Bluetooth 4.0 and Bluetooth 4.1 (optional).

Turning on or off Bluetooth



NOTE: There is no physical switch to enable or disable Bluetooth. It has to be done through the computer settings.

- 1 Swipe-in from the right edge of the display, or click or tap the **Action Center** icon on the task bar to access the Action Center.
- 2 Click or tap **Bluetooth** to turn Bluetooth on or off.

Pairing the Bluetooth-enabled devices

- 1 Turn on Bluetooth. For more information, see <u>Turning on or off</u> <u>Bluetooth</u>.
- 2 Swipe-in from the right edge of the display, or click or tap the Action **Center** icon on the task bar to access the Action Center.
- **3** Right-click or touch and hold **Bluetooth**, and then click or tap **Go to settings**.
- **4** Select the required Bluetooth device for pairing.

5 Click or tap **Pair** to pair the bluetooth devices.



6 Click or tap Yes to confirm the passcodes on both the devices.



Transferring files between devices using Bluetooth

- 1 Swipe-in from the right edge of the display, or click or tap the **Action Center** icon on the task bar to access the Action Center.
- 2 Right-click or touch and hold **Bluetooth**, and then click or tap **Go to** settings.
- **3** Select your Bluetooth device.
- 4 Click or tap Send or receive files via Bluetooth.

5 In the **Bluetooth File Transfer** window, click or tap **Send files**, and then select the file you want to transfer.

← Settings	- o ×
🐯 DEVICES	× Find a setting P
Printers & scanners	 Bluetooth File Transfer
Connected devices	Transfer files using Bluetooth
Bluetooth	You can use Bisetooth technology to transfer files wirelessly between this computer and a Bluetooth device, or between this computer and another Bluetooth enabled computer.
Mouse & touchpad	To continue, select if you would like to send or receive files.
Typing	→ Send files Make sure the computer or device where you plan to send the files is turned on and ready to receive them.
AutoPlay	ready to receive them.
USB	→ Receive files This will allow your computer to receive files sent from another Blastooth enabled computer or divide.
	Next Carcel
📑 🔘 I'm Cortana. Ask	rme anything. 🗇 🔁 📾 🤠 🌩 💰 🔷 🗠 🕫 🔅 658 AM

Removing the Bluetooth device

- 1 Swipe-in from the right edge of the display, or click or tap the **Action Center** icon on the task bar to access the Action Center.
- 2 Right-click or touch and hold **Bluetooth**, and then click or tap **Go to** settings.
- **3** Click or tap the device you want to remove, and then click or tap **Remove device**.



Hard Drive

The following table shows the hard-drive options available in Inspiron 13-7368.

Options	Dimensions		
SSD	M.2 Drive		

Identifying the hard drive

- 1 On the taskbar, click or tap the search box, and then type Device Manager.
- Click or tap Device Manager.
 The Device Manager window is displayed.
- 3 Expand Disk drives.
 - Disk drives
 SanDisk Z400s M.2 2280 128GB

Identifying the hard drive in BIOS setup program

- 1 Turn on or restart your computer.
- 2 Press F2 when the Dell logo is displayed on the screen to enter the BIOS setup program.

A list of hard drives are displayed under the **System Information** in the **General** group.

Media-card reader

The Inspiron 13-7368 has one SD-card slot located on the right side of your computer.

Downloading the media-card reader driver

- **1** Turn on your computer.
- 2 Go to <u>www.dell.com/support</u>.

3 Click or tap **Product Support**, enter the Service Tag of your computer, and then click or tap **Submit**.



NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- 4 Click or tap **Drivers & Downloads** → **Find it myself**.
- 5 Scroll down the page and expand **Chipset**.
- 6 Click or tap **Download** to download the media-card reader driver for your computer.
- 7 After the download is complete, navigate to the folder where you saved the media-card reader driver file.
- 8 Double-click or double-tap the card-reader driver file icon and follow the instructions on the screen to install the driver.

Browsing a media card

- Insert the media card with the metal contacts facing down.
 The card will auto-play and a notification appears on the screen.
- 2 Follow the instructions on the screen.

Keyboard

The Inspiron 13-7368 is shipped with a backlit keyboard.

Changing the keyboard language

- 1 Click or tap Start
- 2 Click or tap Settings
- 3 Click or tap Time & language \rightarrow Region & language.
- 4 Click or tap Add a language.
- 5 Choose the language you want to add and select a country for the language.
- 6 Under Languages click or tap the language that you want to set as the default language.
- 7 Click or tap **Set as default**.

Keyboard shortcuts

Keys	Description
F1 4×	Mute audio
F2 🔹	Decrease volume
F3 •(1)	Increase volume
F4 Hee	Play previous track/chapter
F5 ▶II	Play/Pause
F6	Play next track/chapter
F8	Switch to external display
۶ 9	Search
F10	Toggle keyboard backlight
F11 *	Decrease brightness
F12 *	Increase brightness
Fn + PrtScr	Turn off/on wireless
Fn + B	Pause/Break
Fn + Insert	Sleep
Fn + S	Toggle scroll lock
Fn + H	Toggle between power and battery- status light/hard-drive activity light
Fn + R	System request

Keys	Description
Fn + Ctrl	Open application menu
Fn + Esc	Toggle Fn-key lock
Fn + End →	End
Fn + ←Home	Home
Fn + + PgDn	Page down
Fn + TPgUp	Page up

Touch pad

The Inspiron 13-7368 is shipped with a Precision touch pad.

A precision touch pad is a new class of input device that provides high precision pointer input and gesture functionality. Precision touch pads interact with the operating system directly without a driver.

The operating system handles the overall functionality of the touch pad and there are no separate drivers available for download.

Identifying the touch pad

- 1 On the taskbar, click or tap the search box, and then type Device Manager.
- 2 Click or tap **Device Manager**.
 - The **Device Manager** window is displayed.
- 3 Expand Mice and Other Pointing Devices.
 - Mice and other pointing devices
 - HID-compliant mouse
 - PS/2 Compatible Mouse

Touch pad gestures

Gesture	Procedure	Result
Tap to click	Tap on the touch pad.	Selects an item
Tap, tap-slide to highlight or drag	Tap, tap-slide on the touch pad	Highlights text, and drags and drops an item
Slide to scroll	Place two fingers on the touch pad, and then slide.	Scrolls the page. Pages can scroll left and right, up and down, or both.
Pinch or stretch to zoom	Place two fingers on the touch pad and move them toward each other or away from each other	Zooms in (stretch) or zooms out (pinch) on the touch pad
Swipe for Action Center	Swipe in from the right edge	Opens the Action Center. Swipe again to hide the Action Center.
Swipe for adding new desktop	Swipe in from the left edge	Click or tap New New desktop to add a new desktop

Power adapter

The Inspiron 13-7368 is shipped with a 45 W power adapter.



WARNING: When you disconnect the power adapter cable from the computer, pull on its connector, not the cable itself. When disconnecting cable, keep it evenly aligned to avoid bending any connector pins. When connecting the cable, ensure that the port and the connector are correctly oriented and aligned.



WARNING: The power adapter works with electrical outlets worldwide. However, power connectors and power strips vary among countries. Using an incompatible cable or improperly connecting the cable to the power strip or electrical outlet may cause fire or equipment damage.



NOTE: Depending on the region, two or three pin adapters are available. Please verify part numbers from SPMD before replacing the power adapter.

Battery

The Inspiron 13-7368 is shipped with 3-cell "smart" lithium-ion (43/56 WHr) battery.



NOTE: Batteries are covered for a period of one year from the invoice date unless stated otherwise in the invoice.

Chipset

The chipset is virtually divided into two sections – Northbridge and Southbridge. All computer components communicate with the CPU through the chipset.

The Inspiron 13-7368 is shipped with the chipset that is integrated in the 6th generation Intel Core i3/i5/i7 processors.

Downloading the chipset driver

- 1 Turn on your computer.
- 2 Go to www.dell.com/support.
- 3 Click or tap **Product Support**, enter the Service Tag of your computer, and then click or tap Submit.



NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- 4 Click or tap **Drivers & downloads** \rightarrow Find it myself.
- 5 Scroll down the page and expand Chipset.
- 6 Click or tap **Download** to download the appropriate chipset driver for your computer.
- 7 After the download is complete, navigate to the folder where you saved the chipset driver file.
- 8 Double-click or double-tap the chipset driver file icon and follow the instructions on the screen to install the driver

Identifying the chipset

- 1 On the taskbar, click or tap the search box, and then type Device Manager.
- 2 Click or tap **Device Manager**.

The **Device Manager** window is displayed.

3 Expand System devices.

V System devices
ACPI Fan
ACPI Fixed Feature Button
ACPI Lid
ACPI Power Button
ACPI Processor Aggregator
ACPI Sleep Button
Text ACPI Thermal Zone
Text ACPI Thermal Zone
Tana and the second sec
Emposite Bus Enumerator
The High precision event timer
Intel(R) Integrated Sensor Solution
tal Intel(R) Management Engine Interface
time Intel(R) Power Engine Plug-in
🏣 Intel(R) Serial IO GPIO Host Controller - INT344B
time Intel(R) Serial IO I2C Host Controller - 9D60
🏣 Intel(R) Serial IO I2C Host Controller - 9D61
🏣 Intel(R) Smart Sound Technology (Intel(R) SST) Audio Controller
🏣 Intel(R) Smart Sound Technology (Intel(R) SST) OED
time Intel(R) Virtual Buttons
🏣 ISS Dynamic Bus Enumerator
🏣 Legacy device
🏣 Microsoft ACPI-Compliant Embedded Controller
🏣 Microsoft ACPI-Compliant System
🏣 Microsoft System Management BIOS Driver
🏣 Microsoft UEFI-Compliant System
🏣 Microsoft Virtual Drive Enumerator
🏣 Microsoft Windows Management Interface for ACPI
🏣 Mobile 6th Generation Intel(R) Processor Family I/O LPC Controller (Premium SKU) - 9D48
🏣 Mobile 6th Generation Intel(R) Processor Family I/O PCI Express Root Port #5 - 9D14
🏣 Mobile 6th Generation Intel(R) Processor Family I/O PMC - 9D21
🏣 Mobile 6th Generation Intel(R) Processor Family I/O SMBUS - 9D23
🏣 Mobile 6th Generation Intel(R) Processor Family I/O Thermal subsystem - 9D31
🏣 NDIS Virtual Network Adapter Enumerator
🏣 PCI Express Root Complex
🏣 PCI standard host CPU bridge
🏣 Plug and Play Software Device Enumerator
🏣 Programmable interrupt controller
🏣 Remote Desktop Device Redirector Bus
🏣 System CMOS/real time clock
🏣 System timer

UMBus Root Bus Enumerator

Memory

The Inspiron 13-7368 has two SODIMM (RAM)slots, which are accessible by removing the base cover. Your computer supports 4 GB, 8 GB, 12 GB, and 16 GB dual-channel DDR4 memory of up to 2133 MHz.

Checking the system memory in Windows

- 1 Click or tap Start
- 2 Select Settings දියි.
- 3 Click or tap System \rightarrow About.

Verifying the system memory in BIOS setup program

- 1 Turn on or restart your computer.
- 2 Press F2 when the Dell logo is displayed on the screen to enter the BIOS setup program.
- 3 On the left pane, select **Settings** \rightarrow **General** \rightarrow **System Information**. The memory information is displayed on the right pane.

Testing memory using ePSA

- 1 Turn on or restart your computer.
- 2 Press F12 after the Dell logo is displayed on the screen to access the boot menu.
- 3 Use the arrow keys to highlight the **Diagnostics** menu option and press Enter
- 4 Follow the instructions on the screen to complete the ePSA Pre-boot System Assessment (PSA).



NOTE: If the operating system logo appears, wait until you see the desktop. Turn off your computer and try again.

Processors

The Inspiron 13-7368 is available with the following processor options:

- 6th generation Intel Core i3/i5/i7 ٠
- Intel Celeron Dual Core
- Intel Pentium Dual Core •

Identifying the processors in Windows

- 1 On the taskbar, click or tap the search box, and then type Device Manager.
- 2 Click or tap **Device Manager**.

The **Device Manager** window is displayed.

3 Expand **Processors**.

> Processors Intel(R) Core(TM) i5-6200U CPU @ 2.30GHz Intel(R) Core(TM) i5-6200U CPU @ 2.30GHz Intel(R) Core(TM) i5-6200U CPU @ 2.30GHz Intel(R) Core(TM) i5-6200U CPU @ 2.30GHz

Checking the processor usage in the task manager

- 1 Right-click or touch and hold the taskbar.
- 2 Click or tap Task Manager.

The Task Manager window is displayed.

3 Click or tap **Performance** tab to display processor performance details.

	Startup Users D	etans Servic			
CPU 0% 0.89 GHz	CPU % Utilization	Intel(R)	Core(TM)	i5-6200U CPU @	2.30GH
Memory 2.0/7.9 GB (25%)					
Disk 0 (C:)					
Wi-Fi Not connected					
Bluetooth Not connected	60 seconds Utilization	Speed		Maximum speed:	2.40 GHz
	0%	0.89 0	GHz	Sockets:	1
	Processes	Threads		Cores:	2
				Logical processors:	4
	95	1306	36606		Enabled
	Up time			L1 cache: L2 cache:	128 KB
	0:00:05	5:04		L2 cache: L3 cache:	512 KB 3.0 MB
	0.00.00			L3 cache:	3.0 MB

Operating System

The Inspiron 13-7368 is shipped with the Windows 10 factory installation.

Service Tag location

The service tag is a unique alphanumeric identifier that allows Dell service technicians to identify the hardware components in your computer and access warranty information.

Device drivers

Intel Dynamic Platform and Thermal Framework

In the Device Manager, check if the Intel Dynamic Platform and Thermal Framework is installed.

Install the driver updates from www.dell.com/support.

Intel(R) Dynamic Platform and Thermal Framework
 Intel(R) Dynamic Platform and Thermal Framework Generic Participant
 Intel(R) Dynamic Platform and Thermal Framework Generic Participant
 Intel(R) Dynamic Platform and Thermal Framework Manager
 Intel(R) Dynamic Platform and Thermal Framework Memory Participant
 Intel(R) Dynamic Platform and Thermal Framework Processor Participant

Intel Chipset Software Installation Utility

In the Device Manager, check if the chipset driver is installed.

Install the Intel chipset updates from www.dell.com/support.



Intel HD Graphics 520 driver

In the Device Manager, check if the video driver is installed.

Install the video driver updates from www.dell.com/support.

Display adapters
 Intel(R) HD Graphics 520

Intel Serial IO Driver

In the Device Manager, check if the Intel Serial IO Driver is installed. Install the driver updates from <u>www.dell.com/support</u>. V 🙀 Human Interface Devices Converted Portable Device Control device GPIO Dock Mode Indicator Driver GPIO Laptop or Slate Indicator Driver HID PCI Minidriver for ISS HID-compliant consumer control device HID-compliant system controller HID-compliant system controller HID-compliant system controller HID-compliant system controller HID-compliant touch pad HID-compliant touch screen HID-compliant vendor-defined device HID-compliant wireless radio controls I2C HID Device Microsoft Input Configuration Device Microsoft Input Configuration Device Portable Device Control device USB Input Device USB Input Device USB Input Device

✓ I Mice and other pointing devices

IID-compliant mouse

PS/2 Compatible Mouse



Intel Trusted Execution Engine Interface

In the device manager, check if the Intel Trusted Execution Engine Interface driver is installed.

Install the driver updates from www.dell.com/support.



Intel Virtual Button driver

In the device manager, check if the Intel Virtual Button driver is installed.

Install the driver updates from www.dell.com/support.



Intel Wireless 3165 WiFi and Bluetooth drivers

In the Device Manager, check if the network card driver is installed.

Install the driver updates from www.dell.com/support.



In the Device Manager, check if the Bluetooth driver is installed. Install the driver updates from www.dell.com/support.

Bluetooth
 Intel(R) Wireless Bluetooth(R)
 Microsoft Bluetooth Enumerator
 Microsoft Bluetooth LE Enumerator

BIOS overview

The BIOS manages data flow between the computer's operating system and attached devices such as hard disk, video adapter, keyboard, mouse, and printer.

Entering the BIOS setup program

- **1** Turn on or restart your computer.
- 2 Press F2 when the Dell logo is displayed on the screen to enter the BIOS setup program.

You can change the user-defined settings in BIOS setup program.

Boot menu

The Inspiron 13-7368 includes a one-time boot menu. By using this feature, you can change the sequence of devices that your computer attempts to boot from, for example, floppy, CD-ROM, or hard drive.

Boot menu enhancements

The boot menu enhancements are as follows:

- Easier Access Press F12 to access the boot selection menu.
- User Prompting The user is prompted to use the keystroke on the BIOS screen.
- Diagnostics Options The boot menu includes the ePSA diagnostic options.

Timing key sequences

The keyboard is not the first device initialized by Setup. As a result, if you press a keystroke too early, the keyboard is locked out. In such case, a keyboard error message is displayed on the screen, and you cannot restart your computer with the Ctrl+Alt+Del key combination.

To prevent the keyboard from locking, wait until the keyboard is initialized completely. The keyboard is initialized if one of the following occurs:

- The keyboard lights flash.
- The F2=Setup prompt appears at the top-right corner of the screen during boot.

System diagnostic lights

Power and battery-status light/ hard-drive activity light: Indicates the

battery-charge status or the hard-drive activity.



NOTE: Press Fn+H to toggle this light between power and battery-status light and hard-drive activity light.

Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

Power and battery-status light

Indicates the power and battery-charge status.

Solid white – Power adapter is connected and the battery has more than 5 percent charge.

Amber – Computer is running on battery and the battery has less than 5 percent charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5 percent charge.
- Computer is in sleep state, hibernation, or turned off.

The power and battery-status light blinks amber along with beep codes indicating failures.

For example, the power and battery-status light blinks amber two times followed by a pause, and then blinks white three times followed by a pause. This 2,3 pattern continues until the computer is turned off indicating no memory or RAM is detected.

The following table shows different light patterns, what they indicate, and the suggested solutions.

Light Pattern	Problem description	Suggested solution
2,1	CPU failure	Replace the system board.
2,2	System board: BIOS and ROM failure	Flash latest BIOS version. If problem persists, replace the system board.
2,3	No memory or RAM detected	Confirm that the memory module is installed properly. If

Light Pattern	Problem description	Suggested solution
		problem persists, replace the memory module.
2,4	Memory or RAM failure	Replace the memory module.
2,5	Invalid memory installed	Replace the memory module.
2,6	System board or chipset error	Replace the system board.
2,7	LCD failure	Replace the LCD.
3,1	CMOS battery failure	Replace the CMOS battery.
3,2	PCI or video card or chip failure	Replace the CMOS battery.
3,3	Recovery image not found	Reimage the system.
3,4	Recovery image found but invalid	Reimage the system.

The computer may emit a series of beeps during start-up if the errors or problems cannot be displayed. The repetitive beep codes help the user troubleshoot problems with the computer.

Camera status light: Indicates whether the camera is in use.

- Solid white Camera is in use.
- Off Camera is not in use.

Caps Lock status light: Indicates whether Caps Lock is enabled or disabled.

- Solid white Caps Lock enabled.
- Off Caps Lock disabled.

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:



Learn about your operating system, Se setting up and using your computer, <u>w</u> data backup, diagnostics, and so on.

See Me and My Dell at www.dell.com/support/manuals.

140

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.



NOTE: Availability varies by country and product, and some services may not be available in your country.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.